



INSTRUCTION MANUAL FOR BRUDER "MONTPELIER"
JAPANESE MIYOTA PRECISION QUARTZ
BATTERY: SR927W SONY

- A) DISPLAY AND BUTTONS
- B) SETTING THE DATE CHRONOGRAPH
- C) SETTING THE DAY CHRONOGRAPH
- D) SETTING THE TIME

A) DISPLAY AND BUTTONS



B) SETTING THE DATE CHRONOGRAPH

1. Pull the Crown out to the 1st position.
2. Wind the Crown in an anti-clockwise direction until the date hand is in the desired position.
3. Return the Crown to the normal position.

C) SETTING THE DAY CHRONOGRAPH

4. Pull the Crown out to the 2nd position.
5. Wind the Crown in a clockwise direction until the day hand is in the desired position.
6. Return the Crown to the normal position.

D) SETTING THE TIME

1. Pull the Crown out to the 2nd position.
2. Turn the crown clockwise to set the time.
3. After the time has been set, push the crown back to the normal position.

#WELCOME TO THE BRUDERHOOD